


## Flutter

# Training Assignments

### State management using Bloc

#### **Overview**

In the following tutorial, we're going to build a Counter in Flutter using the Bloc library.



#### **Tasks**

1. Setup

We can then go ahead and replace the contents of pubspec.yaml with

```
flutter_bloc: ^8.1.1
```

2. Creating a Bloc (CounterBloc) and register event handlers (CounterEvent)

```
abstract class CounterEvent {}

class Increment extends CounterEvent {}

class _CounterBloc extends Bloc<CounterEvent, int> {

   _CounterBloc() : super(0) {
      on<Increment>(((event, emit) => emit(state + 1)));
   }
}
```

3. Counter View

```
class _CounterPage extends StatelessWidget {
  final String title;
  const _CounterPage({required this.title});
  @override
 Widget build(BuildContext context) {
    final counterBloc = BlocProvider.of<_CounterBloc>(context);
    return Scaffold(
     - appBar: AppBar(
     — title: Text(title),
      ), // AppBar
     - body: Center(
     — child: Column(
          mainAxisAlignment: MainAxisAlignment.center,
          children: [
           - BlocBuilder<_CounterBloc, int>(builder: (context, count) {
            return Text('$count', style: Theme
                  .of(context)
                  .textTheme
                  .headline1,); // Text
            }) // BlocBuilder
          ],
        ), // Column
      ), // Center
     - floatingActionButton: Column(
        mainAxisAlignment: MainAxisAlignment.end,
        children: [
         - Padding(
            padding: const EdgeInsets.all(8.0),
            child: FloatingActionButton(
              onPressed: () {
                counterBloc.add(Increment());
              },
              tooltip: 'Increment',
            - child: {\sf const} {\sf Icon}({\sf Icons.add}) ,
            ), // FloatingActionButton
          ), // Padding
        ],
      ), // Column
    ); // Scaffold
 }
```

4. Counter Page

#### 5. Run the App

#### Extra tasks

This requirements here is to simulate a TV remote control with 3 simple buttons: volume up, volume down and mute.

